


HT- 860N / ENG + GS1-repl.@

Settings for software Farmis PRO DOS (new current version required) !



1. Factory default

PLEASE WAIT 5 SEC !!!



2. US_EN



3. Transmit FNC_@