

Virtuos BT-310N – prefix TAB, Term CR+LF

(for TRIFID sw)



Restore Factory Default

⌚ čekejte 5 sek. ⌚

Function key Table (Under Function on)



Function ON



Start Configuration((+SETF))



Set All default((+RETF))

⌚ čekejte 5 sek. ⌚

Message Terminator



CR+LF((+C9B))

The Preamble Installation



Appendix A((+E4A))



0



9



End Configuration((+ENDF))