

Virtuos HW-311 – prefix Tab



Restore Factory Default



Function key Table (Under Function ON)

Prefix Setting



Start Configuration((+SETF))



The Preamble Installation - Appendix A((+E4A))



0



9



End Configuration((+ENDF))
