

# Virtuos HW-855A – Prefix F2

Nastavení pro SW Plant-IS od Arbosoft



Restore default CCD module



Factory default for wireless module

⌚ čekejte 5 sek. ⌚



Czech



Keyboard function key (Default)



Add Prefix Setting



~&482&~

F2



Saved and Finished Set